

FR-811 Basic / Demo Parameter settings

In this article you will find Basic / Demo parameters for the FR-811 Hot air rework station

*** NOTE *** PLEASE SET FR-811 TO TC LINK MODE

***Please note that the first (3) Demo Parameters are general guidelines for reference , Actual settings will defer Depending on " Nozzle being used , type of solder , and location of T/C " .

LIGHT DEMO PARAMETERS ARE AS FOLLOWS :

TIMER : OPENED

<u>ZONE</u>	<u>RAMP</u>	<u>TEMP</u>	<u>TIMER</u>	<u>AIR</u>	<u>VACUUM</u>
ZONE1 :	ON	3'C/S	120'C	30S	30% OFF
ZONE2 :	ON	3'C/S	180'C	30S	30% OFF
ZONE3 :	ON	3'C/S	260'C	10S	30% OFF
ZONE4 :	OFF	--'C/S	400'C	30S	50% OFF
ZONE5 :	OFF	--'C/S	500'C	30S	50% OFF
ZONE6 :	OFF	--'C/S	600'C	30S	50% OFF

BOTTOM : MODE

POWER

PREZONE :

ZONE RAMP TEMP POWER TIMER

FR-811 Basic / Demo Parameter settings

OFF --'C/S 150'C 50% 150S

MEDIUM DEMO PARAMETERS ARE AS FOLLOWS :

TIMER : OPENED

	ZONE	RAMP	TEMP	TIMER	AIR	VACUUM
ZONE1 :	ON	3'C/S	120'C	40S	40%	OFF
ZONE2 :	ON	3'C/S	160'C	50S	40%	OFF
ZONE3 :	ON	3'C/S	200'C	30S	40%	OFF
ZONE4 :	ON	3'C/S	260'C	15S	40%	OFF
ZONE5 :	OFF	--'C/S	500'C	10S	50%	OFF
ZONE6 :	OFF	--'C/S	600'C	10S	50%	OFF

BOTTOM : MODE

POWER

PREZONE :

	ZONE	RAMP	TEMP	POWER
TIMER				

FR-811 Basic / Demo Parameter settings

OFF --'C/S 150'C 50% 150S

HEAVY DEMO PARAMETERS ARE AS FOLLOWS :

TIMER : OPENED

	ZONE	RAMP	TEMP	TIMER	AIR	VACUUM
ZONE1 :	ON	3'C/S	120'C	40S	50%	OFF
ZONE2 :	ON	3'C/S	160'C	50S	50%	OFF
ZONE3 :	ON	3'C/S	190'C	30S	50%	OFF
ZONE4 :	ON	3'C/S	200'C	30S	50%	OFF
ZONE5 :	ON	3'C/S	260'C	15S	50%	OFF
ZONE6 :	OFF	--'C/S	600'C	10S	50%	OFF

BOTTOM : MODE

TC

PREZONE :

	ZONE	RAMP	TEMP	POWER
TIMER				

FR-811 Basic / Demo Parameter settings

ON --'C/S 130'C 50% 150S

*** The following Install / Remove Demo's are performed with a standard N51 BGA type nozzle .

999-133 INSTALL DEMO PARAMETERS ARE AS FOLLOWS :

TIMER : OPENED

	ZONE	RAMP	TEMP	TIMER	AIR	VACUUM
ZONE1 :	ON	3'C/S	170'C	40S	50%	OFF
ZONE2 :	ON	3'C/S	210'C	50S	50%	OFF
ZONE3 :	ON	3'C/S	230'C	30S	50%	OFF
ZONE4 :	ON	3'C/S	270'C	15S	50%	OFF
ZONE5 :	OFF	--'C/S	500'C	10S	50%	OFF
ZONE6 :	OFF	--'C/S	600'C	10S	50%	OFF

BOTTOM : MODE

POWER

PREZONE :

FR-811 Basic / Demo Parameter settings

TIMER	ZONE	RAMP	TEMP	POWER
OFF	--'C/S	150'C	50%	150S

999-133 REMOVAL DEMO PARAMETERS ARE AS FOLLOWS :

TIMER : OPENED

	ZONE	RAMP	TEMP	TIMER	AIR	VACUUM
ZONE1 :	ON	3'C/S	120'C	40S	40%	ON
ZONE2 :	ON	3'C/S	160'C	50S	40%	ON
ZONE3 :	ON	3'C/S	190'C	30S	40%	ON
ZONE4 :	ON	3'C/S	200'C	15S	40%	ON
ZONE5 :	OFF	--'C/S	260'C	10S	50%	OFF
ZONE6 :	OFF	--'C/S	600'C	10S	50%	OFF

BOTTOM : MODE

POWER

PREZONE :

FR-811 Basic / Demo Parameter settings

OFF --'C/S 150'C 50% 150S

HakkoUSA Knowledge Base

<http://kb.hakkousa.com/KnowledgebaseArticle11851.aspx>