

Instruction Manual

Thank you for purchasing the HAKKO FR-810 SMD Rework Station.

This unit features:

- Digital control and display of time and temperature
- Digital control and display of air-flow rate
- Preset feature for programming temperature, time, and airflow settings


Please read this manual before operating the HAKKO FR-810.

Keep this manual readily accessible for reference.

1. PACKING LIST AND PART NAMES

Please check to make sure that all items listed below are included in the package.

HAKKO FR-810 station	1	Power cord	1
Handpiece holder	1	Instruction manual	1
FP pick-up (with FP pick-up wire(SS))	1		
Heat resistant pad	1		



2. SPECIFICATIONS

Power consumption	100V-700W 110V-840W 120V-820W 220V-1100W 230V-1200W 240V-1300W
-------------------	---

● Handpiece

Power consumption	100V-670W 110V-810W 120V-790W 220V-1070W 230V-1170W 240V-1270W
Total length (w/o cord)	250 mm (9.8 in.)
Weight (w/o cord)	180 g (0.40 lb.)

* This product is protected against electrostatic discharge.

* Specifications and design are subject to change without notice.

● Station

Power consumption	30 W
Capacity (Airflow)	1 - 9 (5 - 115L/min*)
Control temperature	50 - 600°C (120 - 1120°F)
Outer dimensions	160(W) × 145(H) × 220(D) mm (6.3 × 5.7 × 8.7 in.)
Weight	1.5 kg (3.3 lb.)

* Airflow capacity is rated as free flowing. Restrictions created by various nozzles may reduce the maximum airflow capacity.

※ 各言語（日本語、英語、中国語、フランス語、ドイツ語、韓国語）の取扱説明書は以下のURL、HAKKO Document Portalからダウンロードしてご覧いただけます。
（商品によっては設定の無い言語がありますが、ご了承ください）
* 各言語（日本語、英語、中文、法語、ドイツ語、韓国語）の使用説明書は以下のURL、HAKKO Document Portal からダウンロードしてください。
（一部の製品は設定外語に対応していません、ご了承ください）
* Instruction manual for the language, Japanese, English, Chinese, French, German and Korean can be downloaded from the following URL, HAKKO Document Portal.
(Please note that some language may not be available depending on the product.)

↓
<https://doc.hakko.com>

⚠ CAUTION

This product includes such features as electrically conductive plastic parts and grounding of the handpiece and station as measures to protect the device to be soldered from the effects of static electricity. Be sure to observe the following instructions:

1. The handle and other plastic parts are not insulators, they are conductors. When replacing parts or repairing, take sufficient care not to expose live electrical parts or damage insulation materials.
2. Be sure to ground the unit during use.

中国RoHS：製品中有毒有害物質や元素の名称と含量

部品名称	有毒有害物質や元素				
	鉛(Pb)	汞(Hg)	銅(Cd)	六価クロム(Cr(VI))	多環芳香族(PBB)
電路板	×	○	○	○	○
水平支架	×	○	○	○	○
连接器	×	○	○	○	○
插座	×	○	○	○	○

○：表示該有毒有害物質在該部件所有均質材料中的含量均在SJ/T 11363-2006標準規定的限量要求以下。
×：表示該有毒有害物質至少在該部件的某一均質材料中的含量超出SJ/T 11363-2006標準規定的限量要求。

3. WARNINGS, CAUTIONS AND NOTES

Warnings, cautions and notes are placed at critical points in this manual to direct the operator's attention to significant items. They are defined as follows:

⚠ WARNING: Failure to comply with a WARNING may result in serious injury or death.

⚠ CAUTION : Failure to comply with a CAUTION may result in injury to the operator, or damage to the items involved.

NOTE : A NOTE indicates a procedure or point that is important to the process being described.

⚠ WARNING

To avoid damage to the unit, do not turn the power switch OFF until the pump stops automatical by cooling down after use until **[P-5]** appears on the display.

When powered, the temperature of the hot air and the nozzle will become extremely hot, reaching a maximum temperature of 600°C (1120°F). Be sure of the following to avoid possible **burns / fires** :

- Do not direct the hot air toward personnel or touch the metal parts near the nozzle.
- Do not allow the nozzle to come close to, or touch, flammable materials.
- Inform others in the area that the unit is hot and should not be touched.
- Turn the power off and allow the unit to cool when changing parts or storing the HAKKO FR-810.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.


● To prevent accidents or damage to the HAKKO FR-810, be sure to observe the following:

⚠ CAUTION

- Turn the power off when not in use, or left unattended.
- The unit is for a counter or workbench use only.
- Do not strike the handpiece against hard surfaces or otherwise subject it to physical shock.
- Be sure the unit is grounded. Always connect power to a grounded receptacle.
- Do not modify the unit.
- Use only genuine HAKKO replacement parts.
- Do not allow the HAKKO FR-810 to become wet, or use it when hands are wet.
- Remove the power cord by holding the plug - not the cord.
- Be sure the work area is well ventilated.

4. INITIAL SETUP

● Controls and displays



The front panel of HAKKO FR-810 includes five operation buttons.



- Used to start or stop the station.
 - Pressing this button when the forced cool down bypass is enabled will turn the airflow off and stop the cooling process.



- Used for changing values.
 - Pressing this button when using Preset Mode will cause the preset selection screen to appear.



- Used for changing values.
 - Hold this button for at least two seconds to enter the Offset Mode.



- Used for finalizing entered values and checking settings.
 - Hold this button for at least two seconds to display the temp/timer screen.





- Used to set air flow.
 - When setting the airflow, you may press **[*]** or **[AIR]** to finalize your airflow setting value.

A. Station assembly

- Attach the handpiece holder.


1. Turn and loosen the knob that locks the handpiece holder.
2. Slide the handpiece holder along the groove on the station in the direction of the arrow. Turn the knob to lock the handpiece holder in place.



* The handpiece holder can be attached to either side of the station by removing the handpiece holder attachment plate and attaching it to the opposite side of the handpiece holder.

B. Attaching a nozzle


Aligning the groove on the nozzle with the tabs on the heater pipe and slide the nozzle onto the heater pipe. Turn the nozzle to lock it in place.




4. INITIAL SETUP

C. Electrical connection and power ON

1. Insert the power cord into the receptacle on the rear panel of the station.
2. Place the handpiece on the holder.



The rim of the handpiece must rest on the area circled in the illustration.



⚠ CAUTION

When not in use, place the handpiece on the holder.

3. Plug the other end of the power cord into a grounded wall socket.
4. Turn the power switch ON.


⚠ CAUTION


This product is protected against electrostatic discharge. Be sure the unit is grounded.

5. OPERATION


● Air Blow

1. Start

Press the "S" button on the handpiece or  (START/STOP) button on the station to start blowing air. Hot air blows out of the tip of the nozzle. Hot air temperature is controlled according to the temperature setting.





START/STOP button




"S" button

2. Stop

Press the "S" or  button again. Power to the heater is shut off and cooling begins. When the temperature falls to 100°C (200°F), or after 1.5 minutes of cooling, air blow is automatically stopped. The display will show  indicating that the station is ready to start again.

⚠ WARNING

Do not stop the hot air by turning the power switch OFF.


If power is turned off after use, there will be no cool-down. To avoid damage to the equipment, do not turn the power switch OFF until  appears on the display.

● Setting of the air flow

Pressing the AIR button in the station causes the LED for AIR display to blink and allows you to change air flow. The air flow setting range is 1 to 9.

Actual airflow may be affected by the size and shape of the nozzle(s) used.

Example: Changing the air flow setting from 5 to 7



● Setting/Changing the Temperature and Timer


NOTE:

After accepting the value for the ones digit for temperature, you will have the option to set the timer starting over with the hundreds digit.


The factory default : "Temperature 300°C / 540°F" "Timer --- (No setting)"

Example : When the set temperature is 300°C and the timer setting is ---.


1. Setting the Temperature (from 300°C to 450°C)



2. Setting the Timer (from --- to 130sec)



* When you want to leave the timer "---".



5. OPERATION

* Timer function

In this product, setting the timer allows you to control the time during which hot air is blown.

Either of the following two modes is selectable by parameter setting: Open Timing in which count is started from the time when temperature reaches the set temperature and Closed Timing in which count is started upon start. The timer setting range is 001 to 999 seconds.

(When not using the timer function, select "----". When set in the timer setting "000", don't work.)

● Preset mode

In addition to the procedure described remove above, HAKKO FR-810 includes a preset mode allowing the selection of temperature, time, and airflow from the options you define (up to 5 temperature/time/airflow settings can be programmed). Enter the parameter setting to change the mode.

(Please refer to [● Changing Parameter Settings])


Initial preset settings:

	Temp. : 100°C (212°F) Timer : "----" Air flow : 5		Temp. : 200°C (392°F) Timer : "----" Air flow : 5
	Temp. : 300°C (572°F) Timer : "----" Air flow : 5		Temp. : 400°C (752°F) Timer : "----" Air flow : 5
	Temp. : 500°C (932°F) Timer : "----" Air flow : 5		

The initial number of active presets is set to 5 at the factory.

The default selected preset is set to at the factory.

Example : Changing preset selection from preset No.1 to No.3.



Control will begin with new preset setting.

The procedure for making changes to the preset temperatures, timer and air flow is the same as the "Setting/Changing the Temperature and Timer" and "Setting of the air flow".

● Restriction on setting changes (Password function)

It is possible to restrict certain setting changes to the unit.

There are three choices for the password setting.

Enter the parameter settings to change the mode. (Please refer to [● Changing Parameter Settings])

	0 : Open	1 : Partial	2 : Restricted
Switch to the parameter setting mode	○	×	×
Switch to the temperature setting mode	○	△	×
Switch to the preset selection mode	○	△	×
Switch to the offset setting mode	○	△	×
Make airflow adjustments	○	△	×

○ : You can make changes without entering a password.

△ : You can choose whether or not a password is needed to make changes.


×

Select and input three letters for password from six letters on the right.

A b C d e F

The letters for password

Example: The procedure for changing the set temperature when the unit is restricted by a password. (Password is "AbC")




The unit will move to the change setting screen for each mode after entering the password. Please change the setting for each mode according to the procedure covered in this manual.

● Offset mode {Setting is available within the range of $\pm 50^{\circ}\text{C}$ (90°F)}

⚠ CAUTION

If the total of a set value and an offset value exceeds 600°C , the exceeding portion in the offset value is not effective.

Example: Changing the offset setting from 0°C to -30°C



Each of the set values is displayed for two seconds, and each change is finalized.






5. OPERATION

Other main functions

● Chain Presets function

In this station, when you turn on "Preset mode" and "Chain Presets function" in the parameter settings and set the timer for each preset, available presets are called in from "P-1" to "P-5" allowing you to simulate up to a 5 step rework profile. (The number of available presets changes depending on the setting. Refer to "6. PARAMETER SETTING".)






Example 1)

 Temp. : 100°C (212°F) Timer : "200" Air flow : 2	 Temp. : 200°C (392°F) Timer : "100" Air flow : 3
 Temp. : 300°C (572°F) Timer : "000" Air flow : 5	 Temp. : 400°C (752°F) Timer : "050" Air flow : 5
 Temp. : 500°C (932°F) Timer : "030" Air flow : 6	


Operation : 100°C (200sec) → 200°C (100sec) → 400°C (50sec) → 500°C (30sec)

A preset in which "000" is set in the timer setting is skipped and the next preset is automatically started. (In case of the example 1, this setting corresponds to P3)


Example 2)

 Temp. : 100°C (212°F) Timer : "200" Air flow : 2	 Temp. : 200°C (392°F) Timer : "- - -" Air flow : 3
 Temp. : 300°C (572°F) Timer : "050" Air flow : 5	 Temp. : 400°C (752°F) Timer : "050" Air flow : 5
 Temp. : 500°C (932°F) Timer : "030" Air flow : 6	

Operation : 100°C (200sec) → 200°C

Unless you stop blowing hot air by pressing the "S" or () button manually, the unit will keep up the state if you set "---" in the timer setting. (In case of the example 2, this setting corresponds to P2)
The unit will not move to next step.

● Auto sleep function

When the handpiece is placed in the holder, the automatic sleep function starts working (by default). Pressing the "S" button () in this state will not turn on the station. If the handpiece is placed in the holder while it is blowing hot air, start of automatic cooling is forced before the stop of operation.


⚠ CAUTION

When installing this station, do not place flammable substances behind the outlet of the handpiece. If the handpiece is placed in the iron holder while blowing hot air, serious accidents such as fire may be caused by hot air.

● Auto shutoff function




The auto shutoff function works by default after the station is idle for 30 minutes and it automatically enters a power save state.

● Forced cooling bypass function

With this function enabled, if you press the "S" button () again during cooling, cooling is stopped. This function is used when working temperature is low and you do not have to wait until automatic stop is made. When the set temperature is 380°C or more, the function is unavailable.

























● Check of settings

Example : When the set temperature is 350°C and the timer setting is 150 seconds.

Pressing the () button once allows you to check the settings of the set temperature  and set time  in this order.

6. PARAMETER SETTING

The HAKKO FR-810 has the following parameters:

Parameter name	Parameter No.	Value	Initial value
°C / °F selection		C/F	°F
Auto sleep ON/OFF setting		0: OFF / 1: ON	1
Auto shutoff ON/OFF setting		0: OFF / 1: ON	1
Setting mode selection		0: Normal / 1: Preset	0
The number of preset *		 (2 pcs) ~  (5 pcs)	
Password setting		0: Open/ 1: Partial / 2: Restricted	0
Temperature setting mode **		 :○ /  :×	
Preset selection mode**		 :○ /  :×	
Offset setting mode**		 :○ /  :×	
Air flow mode**		 :○ /  :×	
Password***		A b c d E F Select three letters	-
Auto shutoff time setting		30~60min (Set in units of minutes)	30
Timer mode		o: Open Timing / c: Closed Timing	o
Forced cooling bypass		0: OFF / 1: ON	0
Preset connection ON/OFF setting		0: OFF / 1: ON	0

* It is displayed only when "1:Preset mode" is selected in the setting mode.

** It is displayed only when "1:Custom" is selected in the password setting.

***It is displayed only when either "1:Custom" or "2:valid" is selected in the password setting.

6. PARAMETER SETTING

● 01 : °C or °F temperature display selection

The displayed temperature can be switched between Celsius and Fahrenheit.

● 07 : Auto sleep ON/OFF setting



Select whether you will activate the auto sleep function.

● 08 : Auto shutoff ON/OFF setting

Select whether you will activate the auto shut off function.

● 11 : Setting mode selection

Temperature setting can be switched between the normal mode and the preset mode.

If selecting the preset mode, you will be asked for the number of preset to have available for programming. Press the  or  button to set the number.

● 14 : Password setting

Select "Open", "Partial" or "Restricted" for password setting. If selecting the Restricted, perform the setting for password. If selecting partial, choose whether or not the password function is needed when moving to the temperature setting, preset, offset, and air flow modes and set the password.

● 18 : Auto shutoff time setting

Set auto shutoff time. The setting is available within 30 to 60 minutes in increments of one minute.

● 20 : Timer mode selection

Timer mode setting can be switched between the Opened timing and the Closed timing modes.





● 21 : Forced cooling bypass

Specify whether or not to enable the function that allows you to force the termination of cooling after completion of work. Forced termination in high temperature may cause premature failure of the heating element. Do not use the function except for work in low temperature.











● 22 : Chain Preset setting

Select whether you will activate the Chain Preset function. If you turn on "Preset mode" and "Chain Preset function", available presets are called in sequence from "P-1" to "P-5" allowing you to simulate up to a 5 step rework profile.











● Parameter entering mode

1. Turn off the power switch.
2. Turn on the power switch while pressing the  button.
3. When the display shows , the station is in parameter entering mode.
4. You can switch the parameter No. by pressing the  or .











A. °C or °F temperature display selection

1. Either  or  will be displayed if you press the  button when  is displayed.
2.  and  will be switched alternately If you press the  () button.
3. The display will return to  if you press the  button after selecting.











B. Auto sleep ON/OFF setting

1. Either  or  will be displayed if you press the  button when  is displayed.
2.  and  will be switched alternately If you press the  () button.
3. The display will return to  if you press the  button after selecting.







C. Auto shutoff ON/OFF setting

1. Either  or  will be displayed if you press the  button when  is displayed.
2.  and  will be switched alternately If you press the  () button.
3. The display will return to  if you press the  button after selecting.

D. Setting mode selection

1. Either  or  will be displayed if you press the  button when  is displayed.
2.  (The normal mode) and  (The preset mode) will be switched alternately, if you press the  () button.
3. The display will return to  if you press the  button after selecting.*

* If you select the preset mode, the display will move to the preset selection screen.

4. The number of active preset will be displayed If you press the  button at 3.
(Example : If the number is three,  is displayed.)
5. Press the  () button to change the value and select the number of active preset you required.
The unit will accept values from 2 through 5.
6. The display will return to  if you press the  button after selecting.

6. PARAMETER SETTING

E. Password setting

1. Either , or will be displayed if you press the button when is displayed.
2. If you press the () button, (Open), (Partial) and (Restricted) will be switched alternately.
3. If you press the button after selecting, the display will return to . *1、2

***1 The display will move to the following selection screen if you select (Partial).**

4. If you press the button at 3, you will be asked whether or not the password function is needed when moving to the temperature setting mode.
5. Either (without password) or (with password) will be displayed if you press the () button.
6. If you press the button after selecting, you will be asked whether or not the password function is needed when moving to the preset selection mode.
7. Either (without password) or (with password) will be displayed if you press the () button.
8. If you press the button after selecting, you will be asked whether or not the password function is needed when moving to the offset mode.
9. Either (without password) or (with password) will be displayed if you press the () button.
10. If you press the button after selecting, you will be asked whether or not the password function is needed when moving to the Air flow mode.
11. Either (without password) or (with password) will be displayed if you press the () button.
12. If you press the button after selecting, the display will move to password setting screen.

***2 If you select (Restricted), the display will move to the following password setting screen.**

If you select (Partial), the display will move to the following password setting screen after selecting *1.

11. The hundreds digits in the display will begin to flash. It indicates that you can enter the value.
Press the () button to enter the letter you required.
12. The tens digits in the display will begin to flash if you press the button after entering.
Use the same procedure to enter the letters for tens and units digit.
13. The display will return to if you press the button after entering the units digit.

F. Auto shutoff time setting

1. Auto shutoff time (30 minutes early) will be displayed if you press the button when is displayed.
2. Press the () button, you can change to the desired value. The values you can enter is 30 to 60 (minutes).
3. The display will return to if you press the button after selecting.

G. Timer mode selection

1. Either or will be displayed if you press the button when is displayed.
2. (Open Timing) and (Closed Timing) will be switched alternately If you press the () button.
3. The display will return to if you press the button after selecting.

H. Forced cooling bypass

1. Either or will be displayed if you press the button when is displayed.
2. and will be switched alternately If you press the () button.
3. The display will return to if you press the button after selecting.

I. Chain Preset setting

1. Either or will be displayed if you press the button when is displayed.
2. and will be switched alternately If you press the () button.
3. The display will return to if you press the button after selecting.

After changing parameters, press and hold the button down for at least two seconds until is displayed. At this time, you can switch between and by pressing the () button. Select if you are finished making changes or if you need to go back and make more changes. Press the button to confirm your selection.

Changes will not be completed until is displayed and you press the button.
Please note that no changes will be made if you turn off the power while making changes.


7. TEMPERATURE DISTRIBUTION CHART

⚠ CAUTION


- These charts do not define the temperature characteristics, and are for reference only.
- The temperature distribution charts for HAKKO 850 or 850B should not be used for FR-810. FR-810 uses a different pump and control system. When you use the FR-810, make sure to refer to the temperature distribution charts shown to the under.
- The hot air temperature may not reach the set temperature depending upon the combination of the nozzle and the set air flow. In this case, reduce the set temperature or the air flow.

- Test condition: Measured at a point 1mm (0.04 in.) from the nozzle by recorder.


HAKKO FR-810 Airflow



N51-01 Single ø2.5 (0.10)




N51-02 Single ø4.0 (0.16)




7. TEMPERATURE DISTRIBUTION CHART


N51-03 Single ø5.5 (0.22)



N51-04 Single ø7.0 (0.28)



N51-05 Bent Single 1.5 x 3 (0.06 x 0.12)



8. MAINTENANCE / INSPECTION

⚠ CAUTION


Replacing the heating element is very dangerous. Be sure to turn the power switch OFF and be careful of the following procedure when replacing the heating element.

A. Remove the heating element

1. Remove the 4 screws that attach the heater pipe to the handpiece. Remove the heater pipe.



2. Remove the mica, heat insulation fiber and insulation ring in the heater pipe.



3. Disconnect and remove the heating element.



B. Measure the resistance value

●Normal heater resistance value


Connect an ohmmeter across the connector terminals (a).

The correct values are approximately: 14Ω (±10% 100-110V), 17Ω (±10% 120V), 41Ω (±10% 220-240V).

If the resistance value is incorrect, replace the part.

●Normal sensor resistance value

Connect an ohmmeter across the connector terminals (b). If the resistance value is ∞, replace the part.



Refer to the instructions included with the replacement part.

⚠ CAUTION

Handle the heating element with care. Never touch the heating element wire!

9. TROUBLE SHOOTING GUIDE

⚠ WARNING

Before checking the inside of the HAKKO FR-810 or replacing parts, be sure to disconnect the power plug. Failure to do so may result in electric shock.

● The unit does not operate when the power switch is turned on.

CHECK : Is the fuse blown?
ACTION : Investigate why the fuse blew and then replace the fuse. If the cause can not be determined, replace the fuse. If the fuse blows again, send the unit in for repair.

● **S-E** is displayed

CHECK : Is the sensor broken?
ACTION : Measure the resistance value of the sensor. When the resistance value is ∞, replace the heater.


● **H-E** is displayed

CHECK : Is the heater broken?
ACTION : Measure the resistance value of the heater. The correct values are approximately: 17Ω (±10% 120V and normal temperature). When the resistance value is not within the normal range, replace the heater.

● **F-E** is displayed

ACTION : The fan may be broken. Replace the fan with a new one.


10. PARTS LIST



● HAKKO FR-810

Item No.	Part No.	Part Name	Specifications
①	A5005	Heating element	100-110V
	A5006	Heating element	120.127V
	A5007	Heating element	220-240V
②	B5043	Joint hose	
③	B5044	Fuse/250V-10A	100-127V
	B5060	Fuse/250V-6.3A	220-240V
④	B5045	Pipe	
⑤	B5046	Handle with cord assembly	
⑥	B5048	Handpiece holder	
⑦	B5049	Mica	
⑧	B5050	P.W.B. / 100-127V	
	B5051	P.W.B. / 220-240V	
⑨	B5052	Fan	
⑩	B5053	Power unit	
⑪	B5054	Power cord, 3 wired cord & American plug	U.S.A.
	B2421	Power cord, 3 wired cord but no plug	
	B2422	Power cord, 3 wired cord & BS plug	India
	B2424	Power cord, 3 wired cord & European plug	220V KTL, 230V CE
	B2425	Power cord, 3 wired cord & BS plug	230V CE, U.K.
	B2426	Power cord, 3 wired cord & Australian plug	
	B2436	Power cord, 3 wired cord & Chinese plug	China
	B3508	Power cord, 3 wired cord & American plug (B)	
	B3550	Power cord, 3 wired cord & SI plug	
	B3616	Power cord, 3 wired cord & BR plug	

10. PARTS LIST




● Optional parts

Item No.	Part No.	Part Name	Specifications
①	B5056	FP pick-up	With pick-up wire (SS)
②	B5057	FP pick-up wire (SS)	
③	B2300	Heat resistant pad	
④	B5059	adapter	x2


11. OPTIONAL PARTS (Nozzle)

Unit: mm (in.)


N51-01 Single $\phi 2.5$ (0.1)




N51-03 Single $\phi 5.5$ (0.22)




N51-05
Bent single 1.5x3 (0.06x0.12)




N51-02 Single $\phi 4$ (0.16)



N51-04 Single $\phi 7$ (0.28)




B5058 Conversion adapter




How to Use a old nozzle

1. Attach old nozzle to B5058 Conversion adaptor.



2. Attach B5058 (with old nozzle attached) to the heater pipe.



HAKKO CORPORATION HEAD OFFICE

4-5, Shiokusa 2-chome, Naniwa-ku, Osaka 556-0024 JAPAN
TEL: +81-6-6561-3225 FAX: +81-6-6561-8466
<http://www.hakko.com> E-mail: sales@hakko.com

OVERSEAS AFFILIATES

U.S.A.: AMERICAN HAKKO PRODUCTS, INC.

TEL: (661) 294-0090 FAX: (661) 294-0096
Toll Free (800) 88-HAKKO

<http://www.hakkousa.com>

HONG KONG: HAKKO DEVELOPMENT CO., LTD.

TEL: 2811-5588 FAX: 2590-0217

<http://www.hakko.com.hk>

E-mail: info@hakko.com.hk

SINGAPORE: HAKKO PRODUCTS PTE LTD.

TEL: 6748-2277 FAX: 6744-0033

<http://www.hakko.com.sg>

E-mail: sales@hakko.com.sg

Please access to the following address for the other Sales affiliates.

<http://www.hakko.com>