

How to Determine if FR-810B is in C or F

To quickly and easily determine if the FR-810B is set to C or F without having to go to the parameter settings check the number of digits on the display for the temperature. If the display shows 3 digits, then the unit is set for C. If the display shows 4 digits, then the unit is set for F.

HakkoUSA Knowledge Base

<https://kb.hakkousa.com/Knowledgebase/11689/How-to-Determine-if-FR810B-is-i...>