Can I disable the temperature control lockout card on my HAKKO Fm-202 Soldering Station? If not can I purchase a replacement card somewhere? Mine has been lost.

Replacement lockout key cards ($\mathsf{B2749})\,$ are no longer available for the FM-202 .

NOTE: The following information is provided as-is and is not supported by HAKKO. Modification of any HAKKO product will void the warranty.

To disable the temperature lockout feature on the FM-202 station:

• Remove LED4 from the sensor board inside the unit . This will cause the temperature controller to permanently read as through a key card has been inserted and allow the temperature to be changed.

HakkoUSA Knowledge Base <u>https://kb.hakkousa.com/Knowledgebase/11853/Can-I-disable-the-temperature-c...</u>