

How do I perform a factory reset on the HAKKO FX-100 Soldering Station?

To perform a factory reset on your FX-100 Soldering station. Here are the steps...

1. HOLD Left and Right buttons and Center buttons while turning the unit on.
2. Continue holding the buttons and the display will read INITIAL RESET while the graph counts down going Right to Left.
3. Once the countdown is complete, The display will return to normal function and the Initial reset is now Complete.

If you need additional support please contact American Hakko Products

Support@HakkoUSA.com

1-800-88-HAKKO (42556)

HakkoUSA Knowledge Base

<https://kb.hakkousa.com/Knowledgebase/11917/How-do-I-perform-a-factory-rese...>