

Why does my FA-430 stop pulling smoke shortly after changing filters?

If the FA-430 stops pulling smoke after changing filters, there is an issue with the process that is causing the filters to get clogged. Factors may include things like the work environment, the quality and quantity of the solder and the flux. For information regarding how often to change the filters, please refer to KB article 11975 - "How long do the filters in the FA-430 last before replacement is needed?".

HakkoUSA Knowledge Base

<https://kb.hakkousa.com/Knowledgebase/11980/Why-does-my-FA430-stop-pulling-...>