

ATX Controller Firmware Versions format

Example: Firmware version 0.41.00.0125.0086(124)

- 0.41.00 -> Driver Power Supply Firmware version
- 0125 -> HMI version
- 0086 -> HMI Firmware version
- (124) -> HMI BIOS version

HakkoUSA Knowledge Base

<https://kb.hakkousa.com/Knowledgebase/12025/ATX-Controller-Firmware-Version...>