

What is the size of the four screws that fasten the heater to the housing on the FR-300?

The four screws that fasten the heater to the front of the housing of the FR-300 are M2.6-0.45 x 10mm.

HakkoUSA Knowledge Base

<https://kb.hakkousa.com/Knowledgebase/12028/What-is-the-size-of-the-four-sc...>