## What is the typical service life for the vacuum cups used with the FR-810B and FR-811 SMD Hot Air Rework Stations?

The vacuum cups used generally have a short service life that is dependent on the exposure temperature and time of the exposure. The material is an ESD safe silicone rubber and has a heat resistance of up to 180°C, however during use, the vacuum cups can be exposed to temperatures in excess of 400°C which will cause the material to break down.

When the vacuum cup becomes soft and/or sticky, it is an indication that the vacuum cup is now worn out and should be replaced.

HakkoUSA Knowledge Base

https://kb.hakkousa.com/Knowledgebase/12037/What-is-the-typical-service-lif...