

Noise level analysis DPF200E

Sound level meter position: around 1.40m from the ground, 30° inclination angle, tolerance error +3dBA. All measurements are for reference only.

Ru

LEGEND

D sound level meter distance from the table

1. vacuum system on

2. vacuum system on + spindle on

3. vacuum system on + spindle on + cutting the tab

